VDA116RM Operation Manual

Rack Mount Video 1 x 16 Distribution Amplifier

MicroImage Video Systems division of World Video Sales Co., Inc.

P.O. Box 331 Boyertown, PA 19512 610-754-6800 Fax 610-754-9766 info@mivs.com

www.mivs.com

Contents

Specifications	Page 2
Unpacking	Page 3
Connections	Page 3
In case of difficulty	Page 3
Warranty	Page 4
Returns	Page 4
Pov. 1 . 00	02 2002

Rev 1 08-02-2002

Specifications

 $\begin{array}{lll} \text{Input level} & & \text{1.0 Vpp Composite, 75 } \Omega \\ \text{Output level} & & \text{Same as input into 75 } \Omega \\ \text{Internally adjustable} \\ \text{Connectors} & & \text{BNC female} \\ \end{array}$

Bandwidth

Greater than 30Mhz

Temperature

Operating 0E - 40E C (32E - 104E F)

Storage -40E - 60E C (-40E - 140E F)

Humidity

Operating 10% - 90% (non-condensing)

Storage 5% - 95% (non-condensing)

Power

Voltage 110 - 125VAC, 50/60Hz

Consumption 25W max

Size 19" (W) x 6.7" (D) x 1.7" (H)

482.6 mm (W) x 170.2 mm (D) x 43.2 mm (H)

Weight 2.5 lb.

Manufactured in USA by MicroImage Video Systems

Unpacking

The VDA1116RM package includes the following items:

VDA116RM Video Distribution Amplifier CAB05006 Power Cord 75 ohm 1% Termination This operation manual

Please inspect all items carefully and report damaged or missing items to your dealer or MicroImage Video Systems.

Connections

Power

The VDA116RM uses an industry standard, detachable 3 wire power cord which is included with the unit. For medical applications, a special low leakage cord (MicroImage part # CAB01006) is available. Connect the cord to a suitable power source of 120VAC, 50-60Hz.

Video

Connect the video source (i.e. camera) to the IN connector on the VDA unit. Connect the OUTPUT signals from the VDA unit to the video displays or other equipment as required. Each output must only have a single 75 ohm termination.

The VDA116RM uses female BNC connectors.

In case of difficulty

If you are experiencing problems with your MicroImage product, you can contact us in one of the following ways.

Mail MicroImage Video Systems

a division of World Video Sales Company, Inc.

P.O. Box 331

Boyertown, PA 19512

 Phone
 610-754-6800

 Fax
 610-754-9766

 Email
 support@mivs.com

 Web
 www.mivs.com

Warranty

MicroImage Video Systems warrants that each VDA116RM is free from defects due to faulty materials or improper workmanship for a period of one (1) year. MicroImage Video Systems further warrants that any part which proves defective in materials or workmanship within one (1) year, will be replaced or repaired at no cost to the user. Labor to replace defective parts will be done without charge, provided the equipment is returned to MicroImage Video Systems prepaid, insured and properly packaged. Prior return authorization must be obtained from MicroImage Video Systems.

NOTE

This warranty covers the MicroImage VDA116RM Video Distribution Amplifiers only.

CONDITIONS

This warranty is void if the warranted part has been altered or subjected to abuse or misuse. Defective parts must be returned to MicroImage Video Systems.

SOLE WARRANTY

This Warranty is in lieu of all other warranties expressed or implied including, without limitation, any implied warranty or any implied warranty of fitness for a particular purpose. MicroImage Video Systems shall have the final right to determination as to the existence and cause of any defect and its appropriate adjustment in accordance with the terms of this warranty. In no event shall MicroImage Video Systems be liable for any consequential or collateral damages.

Returns

All returns MUST have an RMA number. Please call, fax or email for an RMA form. The RMA form will have the proper shipping address for returns.

> Phone 610-754-6800 Fax 610-754-9766 Email service@mivs.com