
VDA124RM VDA212RM Operation Manual

Rack Mount Video Distribution Amplifier

VDA124RM 24 Output Unit
VDA212RM Dual 12 Output Unit



P.O. Box 331
Boyertown, PA 19512
610-754-6800
Fax 610-754-9766
info@mivs.com

www.mivs.com

Contents

Specifications	Page 2
Unpacking	Page 3
Connections	Page 3
Power	Page 3
Video	Page 3
Level Adjustments	Page 3
In case of difficulty	Page 3
Warranty	Page 4
Returns	Page 4

Rev 0 11-05-2009

Specifications

Input level	1.0 Vpp Composite, 75 Ω
Output level	Same as input into 75 Ω Rear panel adjustable
Connectors	BNC female
Bandwidth	Greater than 30Mhz
Level Adjustment	One each channel, +/-25%
Temperature	
Operating	0° ~ 40° C (32° ~ 104° F)
Storage	-40° ~ 60° C (-40° ~ 140° F)
Humidity	
Operating	10% ~ 90% (non-condensing)
Storage	5% ~ 95% (non-condensing)
Power	
Voltage	+5VDC, +/- 5%
Consumption	approximately 110mA
Power Module	Included, 120VDC input, 50/60Hz, +5VDC output
Size	19.0" (W) x 2.0" (D) x 1.7" (H) 482.6 mm (W) x 50.8 mm (D) x 43.2 mm (H)
Weight	1.6 lb.
RoHS/Lead Free	Compliant

Manufactured in USA by MicroImage Video Systems

Unpacking

The VDA124RM/VDA212RM package includes the following items:

VDA124RM or VDA212RM Video Distribution Amplifier
+5VDC Power Supply Module
75 ohm 1% Termination (two for VDA212RM)
This operation manual

Please inspect all items carefully and report damaged or missing items to your dealer or MicroImage Video Systems.

Connections

Power

The VDA124RM/VDA212RM uses an external DC power supply to provide power to the unit. It can also be run from a regulated +5VD (+/- 10%) power source. Connect the small plug from the power module to the power connector on the rear of the VDA unit. Plug the power module into a suitable power source of 120VAC, 50-60Hz (USA units).

Video

Connect the video source (i.e. camera) to the IN connector on the VDA unit. A 75 ohm termination (supplied) should be placed on the unused Loop BNC, or on the last unit in the chain if connecting multiple units together.

Connect the OUTPUT signals from the VDA unit to the video displays or other equipment as required. Each output must only have a single 75 ohm termination. The VDA124RM has one set of inputs for all 24RM outputs while the VDA212 has two sets of inputs, each driving a row of 12 outputs. The VDA124RM/VDA212RM uses female BNC connectors.

Level Adjustments

Each row of outputs (12) has a level adjustment accessible via the rear panel. For the VDA124RM, each adjustment affects the top or bottom row of output connectors aligned with the adjustment. For the VDA212RM, each adjustment affects it's respective channel aligned with it. Adjustments can be made via a small flat blade screwdriver.

In case of difficulty

If you are experiencing problems with your MicroImage product, you can contact us in one of the following ways.

Mail MicroImage Video Systems

a division of World Video Sales Company, Inc.
P.O. Box 331, Boyertown, PA 19512

Phone 610-754-6800
Fax 610-754-9766
Email support@mivs.com
Web www.mivs.com

Warranty

MicroImage Video Systems warrants that each VDA124RM/VDA212RM is free from defects due to faulty materials or improper workmanship for a period of one (1) year. MicroImage Video Systems further warrants that any part which proves defective in materials or workmanship within one (1) year, will be replaced or repaired at no cost to the user. Labor to replace defective parts will be done without charge, provided the equipment is returned to MicroImage Video Systems prepaid, insured and properly packaged. Prior return authorization must be obtained from MicroImage Video Systems.

NOTE

This warranty covers the MicroImage VDA124RM/VDA212RM Video Distribution Amplifiers only.

CONDITIONS

This warranty is void if the warranted part has been altered or subjected to abuse or misuse. Defective parts must be returned to MicroImage Video Systems.

SOLE WARRANTY

This Warranty is in lieu of all other warranties expressed or implied including, without limitation, any implied warranty or any implied warranty of fitness for a particular purpose. MicroImage Video Systems shall have the final right to determination as to the existence and cause of any defect and its appropriate adjustment in accordance with the terms of this warranty. In no event shall MicroImage Video Systems be liable for any consequential or collateral damages.

Returns

All returns MUST have an RMA number. Please call, fax or email for an RMA form. The RMA form will have the proper shipping address for returns.

Phone 610-754-6800
Fax 610-754-9766
Email service@mivs.com