
ENC400RM

Operation Manual

Rack Mount
RGB to NTSC and S-Video Encoder

MicroImage Video Systems
division of World Video Sales Co., Inc.

P.O. Box 331
Boyertown, PA 19512
610-754-6800
Fax 610-754-9766
info@mivs.com

www.mivs.com

Contents

Specifications	Page 2
Unpacking	Page 3
Connections	Page 3
Power	Page 3
Video Connections	Page 3
In case of difficulty	Page 3
Warranty	Page 4
Returns	Page 4

Rev 0 01-28-1999

Specifications

Input level	(RGB) 1.0 Vpp Composite, 75 Ω terminated (RGB) 0.714Vpp Non-Comp, 75 Ω terminated (S) 5.0 Vpp max 75 Ω terminated
Output level	(Y & Video) 1 Vpp typical into 75 ohm (C) 0.28 Vpp burst typical into 75 ohm
Connectors	(R, G, B, S, Video) BNC female (S-Video) 4 pin mini DIN F
Resolution	Greater than 400 lines
Modulation	R-Y, B-Y Axes
Genlock	Combination Analog & Digital Synthesis
Sync	Internal (sync on green) or External (default)
Video System	NTSC, RS170
H & V Frequency	15.754 Khz (H), 59.94 Hz (V)
Chroma Frequency	3.579545 Mhz
Temperature	
Operating	0° ~ 40° C (32° ~ 104° F)
Storage	-40° ~ 60° C (-40° ~ 140° F)
Humidity	
Operating	10% ~ 90% (non-condensing)
Storage	5% ~ 95% (non-condensing)
Power	110 ~ 125 VAC, 60Hz, 6W max
Size	19" (483mm) x 6.7" (170mm) x 1.7" (43mm)
Weight	2 lb. 7 oz.
Country of Origin	USA, manufactured by MicroImage Video Systems

Unpacking

The ENC400RM package includes the following items:

ENC400RM
CAB05006 Power cord
This operation manual

Please inspect all items carefully and report damaged or missing items to your dealer or MicroImage Video Systems.

Connections

Power

The ENC400RM has an internal power supply. Connect to a source of 120VAC, 60Hz.

Video Connections

Connect the video source (i.e. camera) to the RGBS IN connectors on the VDA unit. Connect the OUTPUT signals (Video or S-Video) from the ENC400RM unit to the video displays as required.

The ENC400RM is set from the factory to work with external sync. An internal jumper is used to select internal (sync on green).

The RGB signal source **must** meet NTSC RS-170(A) specifications (H & V frequency) for this product to work properly.

In case of difficulty

If you are experiencing problems with your MicroImage product, you can contact us in one of the following ways.

Mail MicroImage Video Systems
a division of World Video Sales Company, Inc.
P.O. Box 331 # Boyertown, PA 19512

Phone 610-754-6800
Fax 610-754-9766
Email support@mivs.com
Web www.mivs.com

Warranty

MicroImage Video Systems warrants that each ENC400RM is free from defects due to faulty materials or improper workmanship for a period of one (1) year. MicroImage Video Systems further warrants that any part which proves defective in materials or workmanship within one (1) year, will be replaced or repaired at no cost to the user. Labor to replace defective parts will be done without charge, provided the equipment is returned to MicroImage Video Systems prepaid, insured and properly packaged. Prior return authorization must be obtained from MicroImage Video Systems.

NOTE

This warranty covers the MicroImage ENC400RM only.

CONDITIONS

This warranty is void if the warranted part has been altered or subjected to abuse or misuse. Defective parts must be returned to MicroImage Video Systems.

SOLE WARRANTY

This Warranty is in lieu of all other warranties expressed or implied including, without limitation, any implied warranty or any implied warranty of fitness for a particular purpose. MicroImage Video Systems shall have the final right to determination as to the existence and cause of any defect and its appropriate adjustment in accordance with the terms of this warranty. In no event shall MicroImage Video Systems be liable for any consequential or collateral damages.

Returns

All returns **MUST** have an RMA number. Please call, fax or email for an RMA form. The RMA form will have the proper shipping address for returns.

Phone 610-754-6800
Fax 610-754-9766
Email service@mivs.com